

# The Effects of Organics Removal on the Methylene Blue Index (MBI)

Taimur Qureshi, Dr. Heather Kaminsky, Andrea Sedgwick and Dr. Yunhui Li

A LEADING POLYTECHNIC COMMITTED TO STUDENT SUCCESS

### Agenda

- Introduction
- Objectives
- Experimental Process
- Results & Discussion
- Conclusions
- Recommendations



#### Introduction


- Methylene Blue Index is used for monitoring clay activity.
- <sup>1</sup>MBI has been correlated with oil sands processing issues.
- Four key steps in the process:
  - 1. Dispersing the clay so it is accessible to the MB dye
  - 2. Acidification of the slurry
  - 3. Gradual addition of the MB dye to the clay slurry
  - 4. Endpoint detection via halo detection




<sup>&</sup>lt;sup>1</sup> Kaminsky, H.A.W (2014) Demystifying the Methylene Blue Index, *Proceedings of the 4th International oil sands tailings conference*, Banff AB.

### Clay Dispersion






















Slide 4

#### MBI Calculation

 The results of the Methylene Blue Index test are reported in several ways but we will just report it as MBI.

$$MBI\left(\frac{meq}{100g}\right) = \frac{mls\ MB \times Normality\ of\ MB}{mass\ of\ dried\ sample\ (g)} \times 100$$



### Objectives

- To evaluate organics removal effects on dispersion of clays.
- To investigate which method is best at removing organics.



### **EXPERIMENTAL PROCESS**




### Methods tested for organics removal from MFT

- Dean and Stark Extraction (D&S)
- D&S +  $H_2O_2$
- Cold wash Slurry MFT with toluene: isopropanol in 76:24 proportion (also known as Unisolv)
- Cold wash Slurry MFT with Tetrahydrofuran (THF)



### Cleaning through Cold-Wash Methods










### **RESULTS & DISCUSSION**




## Does Hydrogen Peroxide affect MB solution?



- The H<sub>2</sub>O<sub>2</sub> cleaning study did not detect a statistically significant effect on MBI solution or check standard clay MB titration.
- UV-vis cannot detect differences between the MBI solutions treated with/without H<sub>2</sub>O<sub>2</sub>.




# Comparison of MB values for D&S vs. D&S+H<sub>2</sub>O<sub>2</sub>



All MBI data were corrected by Kaolinite MBI data.



# Bitumen and Organics were Removed by Unisolv and THF Cold Washing




Cleaning by THF cold washing method provides higher MBI values.

All MBI data were corrected by Kaolinite MBI data.



# Bitumen and Organics were Removed by Different Methods-1



Sonication time (min)	Sonication Energy (Joule/mL)
10	1000
20	2000
30	3000

Grouping information for MFT slurry and cleaned MFT solids with different methods using the Fisher LSD method. Means that do not share a letter are significantly different.




# Bitumen and Organics were Removed by Different Methods-2

- Cold washing with toluene: isopropanol (Unisolv) and THF has resulted in an increased MBI value which could be due to:
  - Easier fines dispersion
  - Better fines/clays capture
  - Better organics removal
- With sonication energy of 1000 Joule/mL, cleaned MFT disperses more easily than MFT slurry.
- With sonication energy higher than 2000 Joule/mL, cleaned MFT via D&S cleaning only does not show a significant difference in MBI values compared to uncleaned MFT slurry.
- The MBI values of THF cold wash cleaned MFT increases with the increase of sonication energy.




#### TGA Results



Under  $O_2$ , MFT solids cleaned by D&S +  $H_2O_2$  have the least total organics.




#### TGA Results



Under N<sub>2</sub>, MFT solids cleaned by THF cold wash have the least weakly bound organics.



### TGA Results – Under Nitrogen



- The sample with higher mass loss (>10 wt%) produced lowest MBI values more organics, worse dispersion.
- For the samples with low mass loss (<10 wt%), the MBI values are not related to the organic contents.

#### Conclusions

- (1) MBI values of D&S cleaned MFT solids show no significant improvement on sample dispersion with the sonication energy higher than 2000 Joule/mL than MFT slurry.
- (2) D&S treated with H<sub>2</sub>O<sub>2</sub> cleaning method increased the MBI value as compared with no H<sub>2</sub>O<sub>2</sub> cleaning step.
- (3) H<sub>2</sub>O<sub>2</sub> cleaning does not affect MBI solution or check standard clay MB titration.
- (4) Cold washing with THF shows the highest MBI values.
- (5) MBI values for D&S solids and uncleaned MFT were similar, this is promising for future online application.

#### Recommendations

- (1) Further TGA analysis under both Nitrogen and Oxygen is required to have more statistical reliability.
- (2) Further investigation is required to see whether D&S solids and raw MFT MBI values compare to operations organics removal or not.

### References

- Currie, A. *Innovations in Methylene blue titration procedures* [PDF document]. Retrieved from www.ptac.org/attachments/1624/download
- Kaminsky, H.A.W (2014) Demystifying the Methylene Blue Index, *Proceedings of the 4th International oil sands tailings conference*, Banff AB.
- Li, Y., Currie, R., Kaminsky, H., Sedgwick, A., & Qureshi, T. (2016). The effects of flocculation on the Methylene Blue Index, *Proceedings of the 5<sup>th</sup> International oil sands tailings conference*, Banff AB: NAIT's Centre for Oil Sands Sustainability.
- Mikutta, R., Kleber, M., Kaiser, K., and Jahn, R. (2005). Review: Organic Matter Removal from Soils using Hydrogen Peroxide, Sodium Hypochlorite, and Disodium Peroxodisulfate, *SOIL SCI. SOC. AM. J.*, *69:* 120-135.
- Stefano, D. C., Ferro, V., & Mirabile, S. (2010). Comparison between grain-size analyses using laser diffraction and sedimentation methods, *Biosystems Engineering 106*: 205-215.



### Acknowledgements

We would like to thank COSIA for allowing us to present this data and for funding this research.



### Questions?

