



LID Technical Workshop – Puget Sound

Bioretention: Design and Construction

Presentation Overview

- Bioretention Basics/Types
- Bioretention Components
- Design by Component
- Layout, Elevation & Grade
- Roadway Challenges
- Construction Considerations

ALICE LANCASTER, PE
alancaster@herrerainc.com

September 10, 2014



BIORETENTION BASICS

BIORETENTION VS. RAIN GARDENS

According to the 2012 Ecology Manual:

- **Bioretention (MR 1-9)**
 - Engineered facility
 - Sized for flow control/WQ goals
 - Designed soil mix
 - May include underdrains/control structures
- **Rain Garden (MR 1-5)**
 - Non-engineered landscape depression to manage stormwater
 - Less restrictive design criteria

BIORETENTION BASICS

BIORETENTION TREATMENT CATEGORY

- **Bioretention is a “bio-infiltration” BMP**
 - Ponding system
 - Treatment via vertical flow through treatment soils while being infiltrated
 - Treatment goal = % volume infiltrated
- **Bioretention is NOT a “bio-filtration” BMP**
 - Flow-through system (ex. biofiltration swale)
 - Treatment via lateral flow through vegetation while being conveyed
 - Treatment goal = hydraulic residence time

BIORETENTION TYPES

BIORETENTION CELLS


- Shallow vegetated depressions
- Gentle side slopes typical
- Not designed as conveyance system
- Optional underdrains/control structures



BIORETENTION TYPES

BIORETENTION SWALES

- Same design features as cells
- Interconnected series of cells
- Provide conveyance (overflow directed to downstream cell)



BIORETENTION TYPES

BIORETENTION PLANTERS

- Vertical walled reservoir (typ. concrete)
- Often used in ultra-urban settings
- Open bottom to allow infiltration to native soil
- Optional underdrains/control structures



BIORETENTION TYPES


BIORETENTION PLANTER BOX

- Same design features as planters
- Closed, impermeable bottom
- Must include underdrain
- Optional control structure




BIORETENTION TYPES

HYBRID- PLANTER SWALE



BIORETENTION COMPONENTS



- Flow Entrance
- Pre-Settling
- Ponding Area
- Bioretention Soil
- Mulch/Compost
- Vegetation
- Filter Fabric (?)
- Liner (optional)
- Underdrain (optional)
- Overflow

FLOW ENTRANCE

DESIGN CRITERIA / TYPES

- Flow entering should be non-erosive
 - Velocity less than 1.0 fps
- Dispersed flow entrance —→ Preferred!
 - Vegetated buffer strip
 - Sheet flow across pavement/gravel
 - Sheet flow b/t wide wheel stops
- Concentrated flow entrance —→ Requires erosion protection (e.g., rock)
 - Piped flow
 - Curb cuts
 - Trench drains

FLOW ENTRANCE

FIELD EXAMPLES



FLOW ENTRANCE

FIELD EXAMPLES



FLOW ENTRANCE

FIELD EXAMPLES

Curb Cut



2012 LID MANUAL

Depressed gutter at inlet

Finish grade should be 2-3" lower than curb line to allow for settling

FLOW ENTRANCE

FIELD EXAMPLES

Trench Drain Curb Cut



Photos courtesy of Portland BES

SW 12TH AVENUE GREEN STREET, PORTLAND, OR

Do not use woody plants at inlet (can restrict or concentrate flows)

FLOW ENTRANCE

FIELD EXAMPLES

Trench Drain



2012 LID MANUAL

For higher/surface elevation inlets

FLOW ENTRANCE

FIELD EXAMPLES


Rock pad for erosion protection



PINEHURST, SEATTLE, WA


FLOW ENTRANCE

DESIGN RESOURCES



Seattle Standard Details

CURB CUT



Seattle Standard Details

CHANNEL WITH GRATE

PRE-SETTLING

DESIGN CRITERIA / TYPES

- To capture debris/sediment and reduce potential for clogging of BSM
- May be required for:
 - For concentrated flow entrances
 - For larger drainage areas
 - Where sediment loading is expected (e.g., high-use parking lots and roadways)
- Pre-settling methods:
 - Vegetated filter strip
 - Fore bay
 - Catch basin

PONDING AREA

PONDING RESERVOIR TYPES



High Point, Seattle, WA
EARTHEN DEPRESSION



Pinehurst, Seattle, WA
ROCKERY WALLS

PONDING AREA

PONDING RESERVOIR TYPES



SplashBoxx
ABOVEGROUND METAL PLANTER




Portland, OR
IN GROUND CONCRETE RESERVOIR

PONDING AREA

DESIGN/PERFORMANCE

Without Underdrain

- Earthen depression (w/o liner) or open-bottomed planter
- Relies on infiltration to native soil
- Can provide effective flow control and WQ treatment




BIORETENTION

PONDING AREA

DESIGN/PERFORMANCE

With Underdrain

- Some infiltration to native soil (w/out liner)
- Cannot meet forest duration flow control (orifice improves performance)
- Can provide effective WQ treatment




BIORETENTION WITH UNDERDRAIN

PONDING AREA

DESIGN/PERFORMANCE

With Underdrain & Liner/Impermeable Container

- No infiltration to native soil
- Typically provides minimal flow control (orifice improves performance)
- Can provide effective WQ treatment



PLANTER WITH UNDERDRAIN

PONDING AREA

SIZING CRITERIA

- Stormwater Management Standards
 - Flow control standards (peak/duration)
 - Water quality standards (infiltrate 91% runoff volume)
- Max. surface pool drawdown time (24-48 hours)
 - Soil allowed to dry out periodically
 - Restore hydraulic capacity of system
 - Maintain adequate soil oxygen levels
 - Prevent conditions supportive of mosquito breeding

$$\text{*Surface Pool Drawdown=} \\ \text{Ponding Depth} \div \text{Design Infiltration Rate}$$

PONDING AREA

SIZING CRITERIA

- Stormwater Management Standards
 - Flow control standards (peak/duration)
 - Water quality standards (infiltrate 91% runoff volume)
- Max. surface pool drawdown time (24-48 hours)
 - Soil allowed to dry out periodically
 - Restore hydraulic capacity of system
 - Maintain adequate soil oxygen levels
 - Prevent conditions supportive of mosquito breeding

*Surface Pool Drawdown=
Ponding Depth ÷ Design Infiltration Rate
Ex. 6 inch ÷ 0.25 inch/hour = 24 hours

PONDING AREA

PONDING AREA SIZE A FUNCTION OF:

Larger Footprint Area for:

- Larger contributing area
- Higher site precipitation
- Lower native soil infiltration rate
- Shallower ponding depth
- Shallower BSM depth

PONDING AREA

CROSS SECTION CRITERIA

- Max ponding depth (12 inches)
- Min bottom width (1 foot)
- Max planted side slope (2.5:1) (for depth ≥ 3 ft)
- Min freeboard?
- Max contributing area or bottom area?

9

PONDING AREA

ROADWAY FACILITY CRITERIA



ROADWAY CROSS SECTION

- 2-foot shoulder
- Grade at 3H:1V
- Grade at 4H:1V for intersections (Seattle)
- Compact shoulder to 90 percent standard proctor

PONDING AREA

ROADWAY FACILITY CRITERIA (SEATTLE)



Pinchurst, Seattle, WA

FIXED OBJECT HAZARDS

- Rockery >1' high, min 10' from curb/edge of road
- Rockery <1' high min 5' from curb/edge of road

PONDING AREA

ROADWAY FACILITY CRITERIA (SEATTLE)




MAXIMUM FACILITY DROP

Max 4' drop from vehicular lane


PONDING AREA

DESIGN RESOURCES




PONDING AREA

DESIGN RESOURCES




PONDING AREA

DESIGN RESOURCES



PONDING AREA

DESIGN RESOURCES




2014 San Francisco Typical Details

BIORETENTION PLANTERS

PONDING AREA

DESIGN RESOURCES




2014 San Francisco Typical Details

BIORETENTION PLANTERS

PONDING AREA

DESIGN RESOURCES



2014 San Francisco Typical Details

BIORETENTION PLANTERS

BIORETENTION SOIL

OVERVIEW

- Purpose
 - Supports plants & microbes
 - Removes pollutants
- Options
 - Amend Native soils in place
 - Over excavate and place imported soil
- Minimum soil depth
 - 12 inches for flow control
 - 18/24 inches for water quality treatment



BIORETENTION SOIL

OVERVIEW

- For treatment → meet Ecology trtmnt soil rqmnts
 - Minimum depth = 18 inches
 - Minimum CEC = 1meq/100g dry soil
 - Organic matter content = 4 – 8%
 - Maximum initial infiltration rate = 12 in/hr
 - Minimum long-term (corrected) rate = 1 in/hr
- Approved BSM Specification in 2012 LID Manual
 - 40% porosity
 - Short-term infiltration rate of 6 inches / hour
 - Design rate of 3 in/hr (for cont. areas up to 5,000 sf)
 - Design rate of 1.5 in/hr (for cont. areas exceeding 5,000 sf)


MULCH/COMPOST

OVERVIEW

- Purpose
 - Reduces weed establishment
 - Regulates soil temp & moisture
 - Adds organic matter to soil
 - Attenuates heavy metals
- Composition
 - Course compost in the bottom of the cell
 - Arborist wood chip mulch composed of shredded or chipped hardwood / softwood on cell slopes
- Depth: 2 to 3 inches
- Alternatives: Dense ground cover or aggregate



FILTER FABRIC??



FILTER FABRIC??

- Typically NOT recommended between existing soil and BSM because of clogging potential
- Gradation difference between existing soil and BSM is typically small so no migration of fines

HYDRAULIC RESTRICTION LAYERS

RESTRICT LATERAL FLOWS

- Geomembranes on vertical walls
- For facilities adjacent to roads, foundations, etc.



2012 LID MANUAL


RESTRICT LATERAL FLOWS

HYDRAULIC RESTRICTION LAYERS


PREVENT ALL INFILTRATION

- Where infiltration is prohibited or not prudent
- Must use underdrain

Impermeable reservoir
(concrete, metal)



IMPERMEABLE PLANTER



BIORETENTION WITH LINER

Clay (bentonite) or
geomembrane

UNDERDRAINS

DO YOU NEED THEM? WHY? WHEN?



BROADVIEW GREEN GRID, SEATTLE, WA

- Where liner is used
- Where infiltration is prohibited or not prudent
- Near sensitive infrastructure with high flood potential
- Soil infiltration rates not adequate to meet surface pool drawdown time

UNDERDRAINS

RECOMMENDED DESIGN

Slotted PVC Pipe with Aggregate Filter Blanket

- Slotted, thick-walled plastic pipe
 - Minimum 4" diameter Schedule 40 PVC
- Slot openings
 - Smaller than smallest aggregate gradation of filter material
 - Slots perpendicular to long axis of pipe
- Gravel filter/bedding material
 - Prevent migration of fine material into drain
 - City of Seattle Mineral Aggregate Type 26 (sandy gravel)
- NOT wrapped in filter fabric

Note: If using City of Seattle Mnri Agg 26, slots shall be 0.069 inches by 1-inch long, spaced 0.25 inches apart. Slots arranged in four rows spaced on 45-degree centers.

UNDERDRAINS

RECOMMENDED DESIGN

PVC Slotted Pipe

Filter Material
(Ag 26)




BR
Soil

UNDERDRAINS

RECOMMENDED DESIGN

- Slotted pipe placement (Seattle)
 - 6" blanket under
 - 12" blanket on top
 - 12" blanket each side



UNDERDRAINS

RECOMMENDED DESIGN BENEFITS


- Increased media area provides better filtering
- Reduced potential for clogging
(versus perforated pipe wrapped in filter fabric)
- More durable and easier to clean
(rotary root cutter or water jet)
(versus perforated PVC or flexible slotted HDPE)



UNDERDRAINS

ADDITIONAL GUIDANCE:

- Minimum underdrain slope = 0.5%
- Observation pipe/clean out
 - 6" rigid non-perforated
 - Every 250 to 300 feet
 - Clean out port
 - Observation well for dewatering rates
- Raised underdrain
 - Maximize infiltration
 - Fluctuating aerobic/anaerobic conditions
→ Denitrification




UNDERDRAINS

ADDITIONAL GUIDANCE:

- Orifice/control structures
 - Improve flow control performance
 - Minimum 0.5" orifice diameter
- Design with access for future modification
 - "Adaptive management"
 - Cap drain pipe
 - Throttle flows with orifice

UNDERDRAINS

DESIGN RESOURCES



OVERFLOW

DESIGN CRITERIA/TYPES

- Necessary to safely convey flows that exceed capacity
 - Typically required unless designed for full infiltration
 - Protect downstream property and resources
- Overflow elevation set at max. ponding depth
- Directed to downstream BMP or approved discharge pt
- Sizing
 - Conveyance sized for local jurisdiction level of service
 - Consider larger overflows (e.g., grade so overflows to ROW)

OVERFLOW

SURFACE OVERFLOW

- Sheet flow
- Gravel level spreader
- Exit curb cut / trench drain



SHEET FLOW OVERFLOW




EXIT CURB CUT TRENCH DRAIN

Portland, OR

OVERFLOW

SUBSURFACE OVERFLOW

- Catch basin
- Vertical stand pipe
- Horizontal pipe
- Can be connected to underdrain system



Broadview Green Grid, Seattle, WA

VERTICAL STAND PIPE WITH BEEHIVE GRATE

LAYOUT OPTIONS

SINGLE CELL

SERIES OF CONNECTED CELLS



Broadview Green Grid, Seattle, WA

SERIES



SINGLE


ELEVATIONS AND GRADE

DESIGN CONSIDERATIONS

- **Cross Slope**
 - Larger footprint area and berming or wall(s) to achieve ponding area
- **Longitudinal Slope (series of flat-bottomed cells)**
 - Optimum slope is 2% / Maximum slope = 8%
 - Steep slopes: control gradient with intermittent weirs or berms or standpipe overflow to provide ponding and dissipate energy
 - Flat slopes: may need weir to create ponding
- **Need positive grade for gravity flow**
 - Inflow from contributing area to bioretention cell
 - Overflow from bioretention cell


ELEVATIONS AND GRADE

CROSS SLOPE



ELEVATIONS AND GRADE

CROSS SLOPE



ELEVATIONS AND GRADE

CROSS SLOPE

Berm & Rockery

BROADVIEW GREEN GRID, SEATTLE, WA

ELEVATIONS AND GRADE

LONGITUDINAL SLOPE- CREATE SERIES OF FLAT-BOTTOMED CELLS

- Check dams / weirs or vertical stand pipe overflow
 - Reduce flow velocities & erosion potential/dissipates energy
 - Create ponding to promote infiltration
- Types of check dams / weirs
 - Compacted earthen berms covered with vegetation
 - Vegetated hedgerows
 - Rock
 - Wood
 - Concrete
- Optimum spacing determined by longitudinal slope, performance goals and cost

ELEVATIONS AND GRADE

MILD LONGITUDINAL SLOPE



Earthen berms

High Point, Seattle, WA

MILD LONGITUDINAL SLOPES

ELEVATIONS AND GRADE

MILD LONGITUDINAL SLOPE

MILD LONGITUDINAL SLOPES

ELEVATIONS AND GRADE

MODERATE LONGITUDINAL SLOPE




Portland, OR (2012 LID Manual)

MODERATE LONGITUDINAL SLOPES

ELEVATIONS AND GRADE

STEEPER LONGITUDINAL SLOPE





110th Street Cascade, Seattle, WA 107th Street Cascade, Seattle, WA

STEEP LONGITUDINAL SLOPES

ELEVATIONS AND GRADE

STEEPER LONGITUDINAL SLOPE





Broadview Green Grid, Seattle, WA

STEEP LONGITUDINAL SLOPES

ELEVATIONS AND GRADE



DESIGN EXAMPLE- LONGITUDINAL SLOPE (WEIRS)



SNOHOMISH COUNTY- UPPER SILVER & NICKEL CREEK LID RETROFIT

ELEVATIONS AND GRADE


DESIGN EXAMPLE- LONGITUDINAL SLOPE (WEIRS)

SNOHOMISH COUNTY- UPPER SILVER & NICKEL CREEK LID RETROFIT

ELEVATIONS AND GRADE


DESIGN RESOURCES




ROADWAY CONSIDERATIONS

CROSS SECTIONS

Example of 20' roadway bio-retention on both sides.
Source: City of Seattle




Example of 20' roadway bio-retention on one side.
Source: City of Seattle



ROADWAY CONSIDERATIONS

UTILITY SETBACKS



- Publicly owned: water, sewer, SW
- Franchise: communications, gas, power
- Horizontal and vertical setbacks
- Mitigation measures if setbacks not met:
 - Liners over utility
 - Sleeve utility
 - Water stops/trench dams

CONSTRUCTION CONSIDERATIONS

- Minimize site disturbance
- Tree protection
- Preventing over compaction
- Erosion and sediment control
- Construction sequencing (covered tomorrow)

CONSTRUCTION CONSIDERATIONS

TREE PROTECTION


- Trees are valuable!
- Arborist evaluation
- Valuation posted on each tree
- Vegetation protection in TESC



CONSTRUCTION CONSIDERATIONS

TREE PROTECTION

- Critical Root Zone (CRZ) →
 - No disturbance
 - Arborist present for construction in CRZ
- Dripline →
 - Fence during construction
- Feeder Root Zone →
 - Limit heavy equipment/stockpiling
 - Limit Trenching
- Utility Boring
 - Tunnel/bore under trees to avoid open cut trench through CRZ and dripline



CONSTRUCTION CONSIDERATIONS

BACK-UP PLAN FOR NATIVE SOIL VARIABILITY

- Do they look like test pit?

- If lower permeability:

- Increase size
- Over-ex and add more BR soil
- Increase ponding depth (if drawdown can be maintained)
- Add underdrain



BROADVIEW GREEN GRID, SEATTLE, WA

CONSTRUCTION CONSIDERATIONS

PREVENTING OVER-COMPACTION

- Prevent over compaction **CRITICAL FOR PERFORMANCE**
- No excavation, soil placement, or soil amendment during wet or saturated conditions
- Operate equipment adjacent to (not in) the facility
- If machinery must operate in the facility, use light weight, low ground-contact pressure equipment

CONSTRUCTION CONSIDERATIONS

VEHICULAR LOADING PRISM- SOME COMPACTION IS NECESSARY



For road or parking lot stability, need heavily compacted from road prism-2H:1V from edge

HIGH POINT, SEATTLE, WA

CONSTRUCTION CONSIDERATIONS

SCARIFY NATIVE SOIL



CONSTRUCTION CONSIDERATIONS

EROSION AND SEDIMENTATION CONTROL

- Protect adjacent properties
- Protect public waterways and storm systems
- Protect installed work
- Protect infiltration systems including swales, soils and porous pavement



HIGH POINT, SEATTLE, WA

RESOURCES

- LID Technical Guidance Manual for Puget Sound
www.psp.wa.gov/LID_manual.php
- Rain Garden Handbook for WWA Homeowners
www.pierce.wsu.edu/water_quality/LID/raingarden_handbook.pdf
- Seattle Public Utilities GSI
www.seattle.gov/util/greeninfrastructure
- Seattle Stormwater Manual
www.seattle.gov/dclu/codes/dlr/DR2009-17.pdf
- Seattle Right-of-Way Improvements Manual
<http://www.seattle.gov/transportation/rowmanual/manual/>
- Portland Sustainable Stormwater
www.portlandonline.com/bes/index.cfm?c=34598
