

# Permeable Pavement Hydrologic Modeling

Alice Lancaster, PE  
Dustin Atchison, PE



September 24, 2014

---

---

---

---

---

---

---

---

## Presentation Overview

- Overview of Hydrologic Modeling
- Performance Standards
- Modeling Guidelines, Tools, Concepts
- Permeable Pavement Types
- Applications
  - Flow Control
  - Water Quality Treatment
  - Slope Considerations
  - Peak Flow Reduction
- Advanced Tools




---

---

---

---


---

---

---

---

## Hydrologic Modeling



Source: <http://www.und.nodak.edu/>

- Q: What is hydrologic modeling?
- A: Use of mathematical equations to estimate runoff based on:
  - weather patterns
  - landuse
  - soil
  - topography

---

---

---

---

---

---

---

---

## Hydrologic Modeling




Figure 1  
The hydrologic cycle

Source: <http://www.und.nodak.edu/>

➤ Q: Why do we use hydrologic models?

➤ A1: Characterize hydrologic conditions

- Predeveloped
- Current
- Post-project

➤ A2: Design mitigation

➤ A3: It's fun!

---

---

---

---

---

---

---

---

## Hydrologic Modeling




Figure 1  
The hydrologic cycle

Source: <http://www.und.nodak.edu/>

➤ Q: When does hydrologic modeling enter into your project?

➤ A: Start to finish

- preliminary design (sizing)
- final design (optimization)
- demonstrate requirements met (permit submittals)

---

---

---

---

---

---

---

---

## Performance Standards

➤ On-site Stormwater Management (MR #5) (NEW 2012)

- Use BMP List (rain garden)
- or
- Meet LID Performance Standard (match flow durations to pre-developed condition from 8% to 50% of the 2-year peak flow )

➤ Runoff Treatment (MR #6)

- Infiltrate 91 percent of the total runoff volume through soil meeting Ecology treatment criteria (for infiltration BMPs)

➤ Flow Control (MR #7)

- Match flow durations to pre-developed condition from 50% of the 2-year to the 50-year peak flow

➤ Other Flow Control Standards

- Combined Sewer or Capacity Constrained Basins (peak-based standards)

---

---

---

---

---

---

---

---

## Modeling Tools

- Single-event models
  - May be appropriate for conveyance sizing
- Continuous models
  - Required for sizing flow control (MR7) and treatment (MR6) BMPs
- Simplified sizing tools
  - Allow sizing without hydrologic modeling

---

---

---

---

---


---

---

---

## Modeling Tools Single-Event Methods

- Input single storm event
- Output peak flow rates
- Typical methods
  - SCS
  - SBUH
  - StormShed
  - SWMM
  - HEC-HMS
  - SUSTAIN




---

---

---

---

---


---

---

---

## Modeling Tools Continuous Models

- Input long-term rain and evaporation
- Output continuous runoff, peak flow, & duration
- Typical programs
  - HSPF
  - WWHM
  - MGS Flood
  - KCRTS
  - SWMM
  - SUSTAIN
  - InfoWorks




---

---

---

---

---

---

---

---

## Modeling Tools Simplified Sizing Tools

- Represent BMP footprint area as % Imp. Area ("sizing factor")
- Prescribed design criteria
- Engineer not needed for small projects (e.g., <10,000sf imp.)
- GSI-Calc available for western WA Lowlands
- Jurisdiction-specific sizing tools also available (e.g., Seattle, Bellevue, Edmonds, Kitsap County, Pierce County)

---

---

---

---

---

---

---

---

## Modeling Tools Simplified Sizing Tools

Kitsap County: Pavement sized as function of contributing impervious area and precipitation

BMP	Design Infiltr. Rate (in/hr)	Forest Standard		Sizing Equation
		M	B	
Permeable Pavement Facility				
6 inch ponding depth	0.25	0.1100	- 1.0536	Area (sf) = Impervious Area (sf) x [M x Precip. (in) + B]
	0.5	0.0187	+ 0.4945	
	1.0	0.0048	+ 0.3531	
Permeable Pavement Surface				
Slope <= 2%	0.13 – 0.249	0.005	0	Aggregate Depth (in) = M x Precip. (in)
	≥ 0.25	0.01	0	

---

---

---

---

---

---


---

---

## Modeling Tools Simplified Sizing Tools

Kitsap County Pre-Sized Calculator

GSI-Calc




---

---

---

---

---

---

---

---

Modeling Guidelines			
(General Summary- See 2012 LID Volume 3, Appendix III-C for details)			
Base Material	Underdrain	Subgrade Slope	Model Surface as:
Above Surrounding Grade	Yes	Any	Impervious surface
	No	Any	Mix landscape/impervious on underlying soil type
Partially or Below Surrounding Grade	Yes	Any	Impervious surface
	No	0-2%	Impervious surface routed to gravel infiltration trench (same size as the pavement area). Trench depth = aggregate depth below surrounding grade
		>2%	Impervious surface routed to gravel infiltration trench (same size as the pavement area). Trench depth = subsurface storage depth if berms (nominal 1/2-inch if no berms)

---

---

---

---

---

---

---

---

### Permeable Pavement Types

Subgrade Slope 0 to 2%

→ can neglect lateral flow  
→ subsurface storage depth modeled = aggregate thickness

---

---

---

---

---

---

---

---

### Permeable Pavement Types

Subgrade Slope >2 to 5% (no berms)

→ cannot neglect lateral flow  
→ subsurface storage depth modeled = average subsurface ponding depth (when no berms, may be estimated as = 1/2")

---

---

---

---

---


---

---

---

## Permeable Pavement Types


Subgrade Slope >2 to 5% (with berms)



## Permeable Pavement Types

Run-on?:


- Always designed to manage rain falling on the permeable pavement area
- May also be designed to mitigate run-on (flow from other areas)



## Modeling Tools

HSPF Basics – Model Inputs

- Meteorological Data
  - Rainfall (5-min, 15-min, hourly)
  - Evaporation (daily)
- Land Cover Types
  - Impervious areas
    - Slope
  - Pervious areas
    - Vegetation
    - Soil type (A, B, C/D)
    - Slope
  - Regional calibrated parameters (Dinicola 1990)
- BMP Configurations




---

---

---

---

---


---

---

---

---

---




---

---

---

---

---


---

---

---

---

---




---

---

---

---

---

---

---

---

---

---

## Permeable Pavement Modeling Examples

- Flow Control in Creek basin (WWHM2012)
- Water Quality Treatment (WWHM2012)
- CSO Reduction (SWMM)

---

---

---

---

---

---

---

---

## Flow Control in Creek Basin WWHM2012 Example – Explicit Method

- Site in King County
- Soil is till (0.25 inch/hour design infiltration rate)
- Permeable pavement *facility* is 10,000 sf
- Receiving run-on from 5,000 sf of additional area
- Design goal = Ecology Stream Duration standard (assuming a predeveloped forest condition)
- Size aggregate depth (*ave. subsurface ponding depth*)
- SIZING FOR FLOW CONTROL GOAL → MAY NEED TO BE THICKER TO SATISFY OTHER DESIGN GOALS (EX. LOADING)

---

---

---

---

---


---

---

---

## Sizing for Flow Control

- Precipitation/Evap. Data → Select county and location on map
- Computational Time Step → 15 minutes




---

---

---

---

---

---



---

---












## Sizing for Treatment

Percent Infiltration- at least 91% of entire runoff file  
Infiltration through soils meeting Ecology treatment soil requirements




## Further Analysis

WWHM2012 Example


## Further Analysis

LID Performance Standard




## Further Analysis

Hydrograph



## Further Analysis


Time Series Export



## Modeling Tools

MGSFlood Basics

- Similar input as presented for WWHM
- Explicit representation of berms and subsurface ponding



## Modeling Tools

### SWMM Basics – Model Inputs


- Environmental Protection Agency's (EPA's) Stormwater Management Model (SWMM)
- Meteorological Data Inputs
  - Rainfall and evaporation
- Land Surface Characteristics
- BMPs
  - LID controls allow explicit modeling of GSI

Table 5-1. Estimating Effective Impervious Surface Area


Subcatchment Type	Basis for TIA	Scaling Factor(s) (%)	Effective Impervious Surface (TIA x SF)
ROW – informal	GIS or site survey	61	Calculated
ROW – curb and gutter	Site survey	95	Calculated
Parcel – w/ existing IMP surface discharges directly to the public drainage system through a pipe or surface channel	Site survey	56	Calculated
Parcel – w/ existing IMP surface discharges to the private pervious surface or private drainage feature (e.g., rock pockets, large vegetated area)	Site survey	28	Calculated

GIS = geographic information system  
 IMP = impervious  
 ROW = right-of-way  
 TIA = total impervious area

## SWMM Basics



## SWMM Basics



## SWMM Basics

### LID Controls

Table 12-1. Composition of Vertical Layers in SWMM5

GSI Type	Surface	Pavement	Soil	Storage	Underdrain
Biosetlement	✓		✓	✓	○
Porous Pavement	✓	✓		✓	○
Bioswale	✓		○	○	○

✓ = required

○ = optional

GSI = green stormwater infrastructure

SWMM = stormwater management model




FIGURE 12-2. FLOW PATHS BETWEEN VERTICAL LAYERS IN PERMEABLE PAVEMENTS

## SWMM Basics

### Permeable Pavement Parameters




FIGURE 12-3. GRAPHICAL USER INTERFACE FOR THE SWMM5 LID CONTROL EDITOR

## SWMM Basics

### Permeable Pavement Parameters

Table 12-4. SWMM5 Input Parameters for Permeable Pavement Facility GSI

Vertical Layer	Property	Description	Unit, Field ID, or Data Type	Example Value	Data Source
Surface	Storage depth	Surface depression storage	Inches	0.1	GSI design
	Surface roughness	Manning's n for overland flow	Dimensionless	0.0115	SWMM5 guidance
	Vegetated surface	Proportion of surface that is vegetated	%	0 for pavements	SWMM5 guidance
	Surface slope	Slope of pavement surface	%	-5%	GSI design
Pavement	Thickness	Thickness of the soil layer	Inches	6	GSI design
	Void ratio	Volume of pore space relative to total soil volume	Fraction	0.15	GSI design
	Impermeable surface fraction	Ratio of impermeable pavement material to total area	Fraction	100	GSI design
	Permeability	Permeability of the pavement layer	Inches/hour	0	GSI design
	Clumping factor	Number of pavement layer void volumes at runoff treated; it takes to completely clog the pavement	Number	0	Not used
Storage	Height	Height of a gravel layer below the soil layer	Inches	24	GSI design



## SWMM Basics

### Permeable Pavement Parameters

Table 12-4. SWMM Input Parameters for Permeable Pavement Facility (SW)

Vertical Layer	Property	Description	Unit, Field ID, or Data Type	Example Value	Data Source
	Void ratio	Volume of void space relative to the volume of solids in the layer	Ratio	0.657	LTCF (equivalent to 3.4 porosity)
	Infiltration rate	Rate at which water infiltrates into the bottom soil below the storage layer	Inches/hour	10	SFU or geotechnical analysis
	Clipping factor	Total volume of treated runoff it takes to completely stop the bottom of the layer divided by the void volume of the layer	Dimensionless	0	Not used


GSI = green stormwater infrastructure  
 LID = low-impact development  
 LTCF = long-term control plan  
 SFU = Seattle Public Utilities  
 SWMM = stormwater management model

## SWMM Basics

### LID Usage Editor

FIGURE 12-8. LID Usage Editor

## Combined Sewer Overflow Reduction SWMM Example




---

---

---


---

---

---

---

---




---

---

---


---

---

---

---

---




---

---

---


---

---

---

---

---




---

---

---

---

---

---

---

---

### Other Metrics Besides Control Volume Reduction

Basin 150	Without GI	Reduction	% Reduction
Control Volume (MG)	0.60	0.16	26%
Events/year	12.2	5.0	41%
Annual Overflow Volume (MG/year)	3.52	0.97	28%

Basin 152	Without GI	Reduction	% Reduction
Control Volume (MG)	5.35	1.04	19%
Events/year	37.5	9.8	26%
Annual Overflow Volume (MG/year)	28.75	9.58	33%

---

---

---

---

---

---

---

---

- ### Resources
- WWHM  
<http://www.clearcreeksolutions.com/>
  - MGSFlood  
<http://www.mgsengr.com/MGSFlood.html>
  - SWMM  
<http://www.epa.gov/athens/wwqtsc/html/swmm.html>
  - HSPF  
<http://water.usgs.gov/software/HSPF/>

---

---

---

---

---

---

---

---

## Questions and Answers

???

---

---

---

---

---

---

---

---

## Contact Information

➤ Alice Lancaster, PE  
[alancaster@herrerainc.com](mailto:alancaster@herrerainc.com)



➤ Dustin Atchison, PE  
[Dustin.Atchison@CH2M.com](mailto:Dustin.Atchison@CH2M.com)



---

---

---

---

---

---

---

---